



Output Cooler

Instructions



Cools spirit as it exits the Reflux Condenser

Additional helpful resources are available at:

www.puredistilling.com.au

Assembly Instructions

- The Output Cooler replaces the standard product arm, remove the product arm and connect the Output Cooler by rotating in a counter-clockwise motion. The connection to the condenser **only needs to be finger tight**, do not overtighten.



Please refer to the above diagram for water connection setup:

- Connection 1 – Attach the cold water inlet from your tap to the bottom of the cooler.
- Connection 2 – Use the short hose supplied with the Output Cooler to connect the top of the cooler to the inlet of the Reflux Condenser (either side is acceptable).
- Connection 3 – Connects to the outlet of the condenser, allowing water to exit the system.

Congratulations you are done - Simply run the Reflux Condenser as per normal, and enjoy!